



CORDLESS DIGITAL DESIGNER™


CUT ~ EMBOSS ~ DRAW

QUICK START GUIDE



STEP 1 - PREP CUTTING MAT


1. Apply a line of adhesive to one end of glass mat.
2. Spread a thin coat across the entire glass mat with foam brush.
3. Allow adhesive to dry for 2 minutes.



STEP 1, # 1 & 2

STEP 2 - POSITION PAPER


1. Place paper directly on glass mat in desired position.
2. Gently smooth paper with hand until paper is flat.



STEP 2, # 1 & 2

STEP 3 - INSERT DESIGN CARD


1. Insert card label side up into back slot of Slice™.




STEP 3, # 1

STEP 4 - TURN SLICE™ ON

1. Plug Slice™ into an electrical outlet.
2. Turn power on by pressing small button on back of Slice™.




STEP 4, # 1




STEP 4, # 2

STEP 5 - SELECT SHAPE & SIZE

1. Use single arrows to scroll through designs & double arrows to change page. Press SELECT to choose shape.
2. After design is chosen, use single arrows to choose size & press SELECT.



STEP 5, # 1




STEP 5, # 2

STEP 6 - CUT DESIGN

1. Press cut button on side of Slice™ to begin cutting.
2. Gently hold Slice™ until check mark appears indicating design cut is complete.
3. Lift Slice™ from mat and remove cut design!



STEP 6, # 1



STEP 6, # 2



STEP 6, # 2